

# Premium+ Universal Chick-N-Nest Box Assembly Instructions


Item #01475

Tools Required: Standard Screwdriver


**A** 4-Wood Screws: 1 3/4"

**B** 4-Bolt & Hex Nut : 2"


Hardware Part #900310



Side Box Panels x2  
#900311




Back Panel  
#900312



Roof  
#900313


Floor x2  
#900314



Center Partition  
#900315


## STEP 1

Attach 2 Side panels Back panel using the 1 3/4" Wood screws (A).




## STEP 2

Remove the Heart-shaped knobs and access panel from your Premium+ Chick-N-Hutch.




## STEP 3

Attach the Nest Box assembly to the side opening of the Hutch wall. Use the four 2" Bolts and Hex nuts (B).




## STEP 4

Place the two Floor panels inside the assembled Nest Box and then the center partition.




## STEP 5


Place the Roof onto the top of the assembled box by making sure the back edge is secure under the side wall.




Chick-N-House  
Item # 01460



Chick-N-Lodge  
Item # 01463



Chick-N-Villa  
Item # 01462



Chick-N-Cabin  
Item # 01461

The Universal Nest Box can be attached to all these Premium Chicken Hutches.

Item #01475



Made in China  
to the exact design specifications of: WARE MFG. INC. Phoenix, AZ 85009, USA  
[www.waremfginc.com](http://www.waremfginc.com)

**WARE**  
Manufacturing Inc.