


Hutch HD Chick-N-Rabbit Pen

Assembly Instructions


Item #01491

#30001491



Unfold Top Panel (C). Align Holes with Side Panels (B) and Front Panel (A). Secure Panels together using **14**-2" Bolts.


Note: small section goes towards the back of Pen.





Attach Back Panel (D) to the bottom of the Chick-N-Hutch, Large Rabbit Hutch or Townhouse Hutch.

Secure with **2**- 2" Bolts





Step 5

Line up the left and right sides of the HD Chick-N-Rabbit Pen to Hutch. Remove wingnut from the upper front side of Hutch and attach "L" shaped bracket using the same wingnut. Secure bracket with **2**- ½" Wood Screws.

Repeat step for lower front side bracket. Perform on opposite side of Hutch also.

Assembly is now complete for your HD Chick-N-Rabbit Pen.





Step 6

Insert a 1½" Wood Screw above the door frame.

The HD Chick-N-Rabbit Pen can be used with the

- HD Chick-N-Hutch (Item #01490)
- HD Large Rabbit Hutch (Item #01550)
- HD Townhouse Hutch (Item #01509)





Tip: This item (as any wood) should be periodically (every 12 to 18 months depending on climate) treated with a non-toxic exterior grade stain.

MADE IN CHINA to the design specifications of WARE MFG., INC. Phoenix, AZ 85009, USA WWW.WAREMFGINC.COM

If your new pet home experienced damage during shipping, **DO NOT RETURN TO THE STORE.** Contact our customer service department at **1-800-295-2243** and we will help you with any problems, Mon-Fri 8:00 – 4:00 MST or through our website at *www.waremfginc.com*