

Warning: Please Read and Follow all Instructions Before Installation

Packing List:

Assembled Door Unit, Installed motor
Timer, Adapter, 4-mounting screws



Step 1
Remove the 8 screws from the aluminum panel



Step 2
Remove the aluminum panel
This panel protects the motor



Step 3
Remove the shipping block just to the right of the motor



Step 4
Remove the second shipping block in the smaller section of the door



Step 5
Insert the adapter plug into the hole on the top left corner of the unit



Step 6
Insert the plug into the motor box found on the bottom of the motor



Step 7
Now you are ready to test your unit. Stand your unit in the upright position and plug your adapter into a receptacle. The door will now shut.



Step 8
Unplug the adapter from the receptacle and wait for 5 seconds, you should hear a small click. Plug the adapter back into the receptacle the door will now open.



Step 9
Install 2 screws at the top of the unit and secure it to the inside of your coop



Step 10
Install 2 screws at the bottom of the unit and secure it to the inside of your coop



Step 11
Program the timer using the instruction manual provided. Plug the timer into the receptacle



Step 12
Plug the adapter into the timer. Check the timer to make sure it opens and closes at the desired times.



Step 13
Install the aluminum panel that covers the motor.



Step 14
This completes your installation. Clean the unit weekly to keep it working properly.

